The special instructions for new Cargo bikes

1. Assembling the battery

   Firstly put the battery box into the frame under the carriage. Fix the battery box with battery hook and battery clamp provided.



   Then open the switch(A).



2. Speed switch

Ⅰ: low speed

Ⅱ: high speed

Ⅲ: middle speed

3. Gear shift

The new Cargo bike has two gears, high-grade and low-grade. When climbing and very difficult to climb, you can stop the Cargo bike, and then change the low-grade to climb.



Note1: When changing the gears, you must stop the Cargo bike.

Note2: When stopping the Cargo bike, please pull the hand brake.